

HAMMERHEAD

PACKING/UNPACKING INSTRUCTIONS

To Unpack

Cut the vertical two (2) steel bands. *Do not cut the horizontal bands!*

Remove the hex head screws holding the crate to the skid. There are three (3) per side with a total of twelve (12). A 5/16" socket driver is needed. **SAVE THE SCREWS!** The screws are outlined in black paint. **NOTE: There are two length screws, the long go on the sides!**

Lift off the crate from the skid. Remove the tie-down strap holding the machine to the skid. **SAVE THE TIE-DOWN STRAP!**

Remove the power cord box and the wire pole assembly. **SAVE THE PACKING!**

Lift the machine off the skid onto the floor. **The machine weighs 300#, use 3 people, one on each side and one at the handle.**

Remove the protective bag over the coil cord from the handle assembly. **SAVE THE BAG!**

To Re-pack

Reverse the above procedure. **Be sure to line up the crate to skid markings... Front to Front, Right to Right, etc. The machine can only go on the skid in one direction. Orient the machine according to the markings!**



NOTE: Do not strap over the wire pole! Strap only as shown.

HID Ultraviolet

